

Installing the Ozan

The Ozan is a half circle made out of the liner material. It sits on top of the liner and serves as an interior ceiling that catches water drips and also traps heat underneath it. Ozans typically have a 6 inch lip that serves as seal with the liner.

To install the ozan, start with the ties that are on the upper side in the center back, opposite the center loop (1). Tie the ties to the upper liner rope and slit the fabric with a utility knife each time you come to a pole. This way you will create a nicely fitting overhang on the outside of the liner.



Use part of your liner rope to tie up the front edge of the ozan. To do this, run the rope through the center loop (1) and use a ladder to tie it high to the poles, to avoid too much sagging. Photo (2) shows an ozan on top of a 9 ft. liner. If you have an ozan on top of a 6 ft. liner, you might wan to hang the outer edges higher up as well, to give you enough walking space underneath (3).

