



## Installing Liner and Door Snakes

The Liner Snakes are 6 ft. long canvas tubes that have a velcro closure at one end. They are filled with sand or gravel and used to weigh down the liner to give it a snug fit with the floor. The Door Snake is a 3 ft. long canvas tube with a fabric flap that will help cover the gap below the door entrance.



You can purchase sand or gravel from a home improvement store or a gravel pit. You can also go out into Nature and find sand or gravel that you can use (3). Gravel is 'cleaner' than sand in case the velcro bursts open, although normally that does not happen if it is closed well.

Use a funnel to pour the gravel or sand down the tubes. Once they are filled with gravel or sand, these 6 ft. sand snakes can weigh up to 35 lbs (4).



Position the liner snakes above the 6 inch liner lip and push them towards the lower liner rope. This gives the liner a tight fit at the bottom (1). The Door Snake has ties that you can tie to the door poles and also to the pins below the door opening (2). Campground Models use velcro to attach their door snakes.